

Tropitone®



For additional Cabana Club assembly and product care instructions, see www.tropitone.com and select Product Care.

- ✓ Cabana Club Cleaning and Care
- ✓ Cabana Club Woven Panel Attachment
- ✓ Cabana Club Party Lounger and Natural Stone Drink Table Assembly Instructions

If you have difficulty understanding any of the instructions and need assistance while fastening your components together, please call Tropitone's Customer Service Center at 949-951-2010.

Tropitone Furniture Co., Inc.
5 Marconi, Irvine, CA 92618

949 951 2010 phone
www.tropitone.com

Part # R9TCCCAI
Revised: 05.09.2013
©2013 Tropitone Furniture Co., Inc.

Tropitone®

*Assembled furniture
is heavy. Assemble
at place of use.*

Cabana Club Collection Component Assembly Instructions

Congratulations on the purchase of your Tropitone Cabana Club Collection. Read through all steps before fastening components together.

CAUTION: Do not try to lift or flip furniture components with only one person. Components may be heavy and awkward to handle, and may result in injury to persons or damage to property if not lifted properly.

Tools Required

7/16" Combination Wrench

Safety Glasses

Parts List

- (2) Connector Plates (example: connecting 2 modules)
- (4) 1/4-20 x 7/8" Hex Head Bolts
- (4) 1/4" Flat Washers
- (4) 1/4" Lock Washers

- ✓ Check that all items listed in the Parts List are in your carton.



Step 1

Components can be assembled in upright position by reaching under frame members. Proceed to next step.


OR

Prepare a smooth, non-scratch surface (a tarp or pool towels can be placed on your work surface) so the components can be placed side-by-side for assembly. With two persons, tilt the components onto their side to allow access to the bottom of the pieces. Insure flat side surfaces are down for stability and the helper is holding the furniture components stable.


NOTE: If three (3) or more components are being fastened together, the components should be assembled in an upright orientation. This is especially critical when components are being assembled into a non-linear configuration.

Step 2

Using a 1/4-20 x 7/8" hex head bolt with 1/4" flat washer and 1/4" lock washer, attach a connector plate through the slotted hole into one furniture component. Tighten the screw hand tight so the plate can swing.



Repeat with the other connector plate.



Step 3

Swing the connector plates so the slotted hole overlaps the drilled hole. Install a hex head bolt with flat washer and lock washer into the second furniture component – hand-tighten both hex head bolts.

Repeat with the other connector plate.

Fully tighten thumb screws with the screwdriver (4 places).

Step 4

Repeat Step 2 and Step 3 for each additional furniture component until all components are fastened together into the desired configuration.

Step 5

If components are in upright position, proceed to next step.

OR

Your furniture should now be fully assembled and ready to tilt into an upright position. It is especially critical two or more persons tilt assembled furniture into the upright position to prevent injury or damage to furniture.

Step 6

Place the seat cushions with zipper down onto each furniture component. Components with a back or side have notches in the seat cushion; the notch fits to the frame members.

- Stainless Steel – (rod seat deck grid): Wrap the snap straps around the seat deck grid; snap closed to the tightest snap.
- Aluminum – (wide, flat strap seat deck grid): Wrap the snap straps around the seat deck grid; snap closed to the second snap.

Place the seat backs with zippers down onto each furniture component. The corner module back pieces have a left and right; the corner receives the “wedge”. Connect the snap to the underside of the back frame member.

Add the optional throw pillows and bolsters, then enjoy!